

Writing a Simple Procedure in Karabo (How to Macro)

Anna Klimovskaia
Controls Group


Schenefeld, 01.03.2024



Macro Fundamentals

The Karabo framework provides scripting facilities which enable Instrument scientists to develop so-called "macros".

Macros are short python scripts that give the flexibility to write ad-hoc code by instrument staff directly in a karabo GUI without the involvement of CTRL group.



Macro Benefits


- Macros can be written quickly by karabo users
- Macros can be saved as part of project configurations – covers recurring task and calculations
- Macros may be executed from the GUI
- Simple syntax, while the same as middle-layer device
- Interaction with karabo devices

Macro Limitation

- Macros by concept should be restricted to simple
- Should not have state machine (Only ACTIVE and PASSIVE automatically set)
- Can be canceled
- Macros utilize the Karabo Middlelayer API interface. However, macros are only suitable for simple use cases
- There is no version control and limited support from CTRL group

How To Create Macro


- Connect to karabo (admin, localhost:44444)
- Open project
- Select the macro folder
- Right-click and then click Add macro
- Fill the dialog with a macro-name
- As a result – new macro is added to the project with default content



Macro Content

- Import from middlelayer api
- A Macro class
- Properties (Karabo descriptors), e.g. String
- MacroSlots to execute assigned functions

Note: A Macro always comes with a Cancel Slot - no need to define it



Macro Content

- Import from middlelayer api
- A Macro class
- Properties (Karabo descriptors), e.g. String
- MacroSlots to execute assigned functions

Note: A Macro always comes with a Cancel Slot – no need to define it

The screenshot displays the Karabo Configuration Editor interface. On the left, the 'Projects' panel shows a tree structure with 'WORKSHOP_24_Session1' expanded, containing 'Macros' and 'Template'. The 'Template' macro is selected. The main editor shows the Python code for the 'Template' macro class:

```
1 from karabo.middlelayer import Macro, MacroSlot, S
2
3
4 - class Template(Macro):
5     name = String(defaultValue="Template")
6
7     @MacroSlot()
8     def execute(self):
9         print("Hello {}".format(self.name))
10
```

Below the code editor, a log window shows the connection status: 'Macro-Template-1c75887b-9f2d-4e8e-b8d6-520033b7a93c Connecting to Macro-Template-1c75887b-9f2d-4e8e-b8d6-520033b7a93c ...Connection done!'.

On the right, the 'Configuration Editor' panel shows a table of properties and their current values on the device:

Property	Current value on device
ClassID	Template
Class version	builtins-2.20.0a5
Karabo version	2.20.0a5
ServerID	karabo/macroServer
Host	cas-lab-sys-conl-2
Process ID	15194
State	PASSIVE
Status	none
Alarm condition	none
Locked By	
Last command	
Logger	
Project	WORKSHOP_24_Session1
Module	Template
Current Slot	
Printed output	
Number of prints	0
Available Macros	['macro']
name	Template

At the bottom of the configuration editor, there are buttons for 'Clear Lock', 'Cancel', 'execute', and 'Shutdown instance', along with an 'Apply all' button.

Code Style

- Class Definitions – CamelCase starting with capital letter
- Class Properties - camelCase, whereas non-exposed variables should have `_underscores`
- Slots are camelCase, methods have `_underscores`.
- It is preferred to check for conditions to be correct rather than using exceptions
- Use Double and NOT Float

```
class MyMacro(Macro):  
    pass  
  
class CallDRC(Macro):  
    pass
```


Code Style

- Class Definitions – CamelCase starting with capital letter
- Class Properties – camelCase, whereas non-exposed variables should have `_underscores`
- Slots are camelCase, methods have `_underscores`.
- It is preferred to check for conditions to be correct rather than using exceptions
- Use Double and NOT Float

```
name = String(displayedName="Name")

someOtherString = String(
    displayedName="Other string",
    defaultValue="Hello",
    accessMode=AccessMode.READONLY)

valid_ids = ["44eab", "ff64d"]
```

Code Style

- Class Definitions – CamelCase starting with capital letter
- Class Properties – camelCase, whereas non-exposed variables should have `_underscores`
- Slots are camelCase, methods have `_underscores`.
- It is preferred to check for conditions to be correct rather than using exceptions
- Use Double and NOT Float

```
@MacroSlot(displayedName="Execute")
def executeMe(self):
    await self.some_action()

def some_action(self):
    pass
```

Code Style

- Class Definitions – CamelCase starting with capital letter
- Class Properties – camelCase, whereas non-exposed variables should have `_underscores`
- Slots are camelCase, methods have `_underscores`.
- It is preferred to check for conditions to be correct rather than using exceptions
- Use Double and NOT Float

Therefore, the following `is` discouraged:

```
def execute_action(self):  
    try:  
        await self.px.move()  
    except:  
        pass
```

But rather:

```
def execute_action(self):  
    if self.px.state not in {State.ERROR, State.MOVING}:  
        await self.px.move()  
    else:  
        pass
```

Code Examples

- Template – default macro content
- NewProperty – add new property
- NewPropertyAttributes – property attributes
- MacroSlot – add slot (button)
- GetProperty – get property from another device
- SetProperty – set new value to another device
- GetConfiguration – get full configuration
- RemoteDevice – monitor remote device
- InstantiateDevice – instantiate device with required configuration


Template

- Import
- Instantiate on macro server
- Instantiate on development macro server
- Slot is a button
- Execution output

```
1 from karabo.middlayer import Macro, MacroSlot, String
2
3
4 - class Template(Macro):
5     name = String(defaultValue="Template")
6
7     @MacroSlot()
8     - def execute(self):
9         print("Hello {}!".format(self.name))
10
```

NewProperty

- Different types
- Properties order



```
1 from karabo.middlelayer import Int32, Double, Macro
2
3
4 -class NewProperty(Macro):
5
6     currentVoltage = Double(defaultValue=0.0)
7     steps = Int32()
```

NewPropertyAttributes

- Import
- List of attributes

```
1  - from karabo.middlelayer import (  
2      AccessMode, Assignment, Double, Macro, MetricPrefix, Unit  
3  )  
4  
5  
6  - class NewPropertyAttributes(Macro):  
7  
8      - currentVoltage = Double(  
9          displayName="Current Voltage",  
10         description="Current Voltage of pico motor",  
11         defaultValue=0.0,  
12         assignment=Assignment.OPTIONAL,  
13         accessMode=AccessMode.READONLY,  
14         unitSymbol=Unit.VOLT,  
15         metricPrefixSymbol=MetricPrefix.KILO)  
16
```

Task1 - NewPropertyAttributes

- Add new Int32 property
 - Don't forget to import proper type
 - Change property key
 - Set new default value

```
1 - from karabo.middlelayer import (  
2     AccessMode, Assignment, Double, Int32, Macro, MetricPrefix, Unit  
3 )  
4  
5  
6 - class NewPropertyAttributes(Macro):  
7  
8     - currentVoltage = Double(  
9         displayedName="Current Voltage",  
10        description="Current Voltage of pico motor",  
11        defaultValue=0.0,  
12        assignment=Assignment.OPTIONAL,  
13        accessMode=AccessMode.READONLY,  
14        unitSymbol=Unit.VOLT,  
15        metricPrefixSymbol=MetricPrefix.KILO)  
16  
17     - newInt = Int32(  
18         displayedName="int32",  
19         defaultValue=1)  
20
```


MacroSlot

- Import
- Execution output



```
1 from karabo.middlelayer import Macro, MacroSlot, String
2
3
4 - class MacroSlot(Macro):
5
6     name = String(defaultValue="Macroslot")
7
8     @MacroSlot()
9     - def printName(self):
10         print(f"Hello {self.name}!")
```

Task2 - MacroSlot

- Calculate new value and set to macro property
 - Update import
 - Change displayed name
 - Add new properties
 - Set new value x2

```
1 from karabo.middlayer import AccessMode, Int8, Macro, MacroSlot, String
2
3
4 - class MacroSlot(Macro):
5
6     name = String(defaultValue="Macroslot")
7
8     @MacroSlot()
9     - def printName(self):
10         |     print(f"Hello {self.name}!")
11
12     newInt = Int8()
13
14     @MacroSlot()
15     - def multiplication(self):
16         |     self.calculatedInt = self.newInt*2
17
18     calculatedInt = Int8(accessMode=AccessMode.READONLY)
19
```

GetProperty

- Import
- GetProperties input parameters

```
1 from karabo.middlayer import Macro, MacroSlot, String, getProperties
2
3
4 - class GetProperty(Macro):
5
6     @MacroSlot(displayedName="Read Value")
7     - def readString(self):
8     -     self.name = getProperties("SESSION1/CPP/PROP_TEST1",
9     -                             ["stringProperty", "int8Property"])["stringProperty"]
10
11     name = String(displayedName="Value on Device")
12
```

SetProperty

- Import
- Scene Set_Value



```
1 from karabo.middlelayer import Int8, Macro, MacroSlot, setWait
2
3
4 - class SetProperty(Macro):
5     number = Int8(defaultValue=1)
6
7     @MacroSlot()
8     - def setInt(self):
9         new_value = self.number.value * 2
10        setWait("SESSION1/CPP/PROP_TEST1", "int8Property", new_value)
11
```


Task3 - SetProperty

- Add new slot to set any other property on remote device
 - Don't forget to import proper type
 - Change property key
 - Change set property key

```
1 from karabo.middlayer import Int8, Macro, MacroSlot, setWait, String
2
3
4 - class SetProperty(Macro):
5     number = Int8(defaultValue=1)
6
7     @MacroSlot()
8     - def setInt(self):
9         new_value = self.number.value * 2
10        setWait("SESSION1/CPP/PROP_TEST1", "int8Property", new_value)
11
12    newString = String()
13
14    @MacroSlot()
15    - def setStr(self):
16        setWait("SESSION1/CPP/PROP_TEST1", "stringProperty", self.newString)
17
```

GetConfiguration

- Import
- getConfiguration input parameters



```
1 from karabo.middlayer import Int32, Macro, MacroSlot, getConfiguration
2
3
4 - class GetConfiguration(Macro):
5
6     @MacroSlot()
7     - def execute(self):
8         config = getConfiguration("SESSION1/CPP/PROP_TEST1")
9         print(config.keys())
10        self.testInt = config["int32Property"]
11
12    testInt = Int32()
13
```

RemoteDevice

- Import
- RemoveDevice input parameters
- WaitUntilNew
- Change monitoring property

```
1  - from karabo.middlayer import (  
2      Macro, MacroSlot, RemoteDevice, String, waitUntilNew  
3  )  
4  
5  
6  - class RemoteDevice(Macro):  
7  
8      remote_device = RemoteDevice('SESSION1/CPP/PROP_TEST1')  
9  
10     - monitoringProperty = String(  
11         |     displayName="Monitoring property",  
12         |     defaultValue="int8Property")  
13  
14     @MacroSlot(displayName="Start Monitoring")  
15     - def startMonitor(self):  
16     -     while True:  
17     -         current_monitor_prop = getattr(self.remote_device,  
18         |                                     | self.monitoringProperty)  
19         | print(f"Received {current_monitor_prop.value}")  
20         | waitUntilNew(current_monitor_prop)  
21
```

InstantiateDevice

- Import
- Sleep
- Set several properties on instantiation

```
1 - from karabo.middlayer import (  
2     instantiate, Hash, Macro, MacroSlot, sleep, String, shutdown  
3 )  
4 import datetime  
5  
6 - class InstantiateDevice(Macro):  
7     name = String(defaultValue="WORKSHOP/SLEEPY/ONE")  
8  
9     @MacroSlot()  
10    - def execute(self):  
11        h = Hash()  
12        current_time = datetime.datetime.now()  
13        h["stringProperty"] = str(current_time)  
14        instantiate('cppServer/session1', 'PropertyTest', self.name, h)  
15        print(f"device {self.name} is instantiated with sting: {current_time}")  
16        sleep(10)  
17        shutdown(self.name)  
18        print(f"device {self.name} shutdown")  
19        sleep(2)  
20
```


Task4 - InstantiateDevice

- Add several properties to initial device configuration
 - Import types
 - Add new property to hash

```
2      instantiate, Hash, Macro, MacroSlot, sleep, String, shutdown
3  )
4  import datetime
5
6  - class InstantiateDevice(Macro):
7      name = String(defaultValue="WORKSHOP/SLEEPY/ONE")
8      newInt = Int8(defaultValue=1)
9
10     @MacroSlot()
11     - def execute(self):
12         h = Hash()
13         current_time = datetime.datetime.now()
14         h["stringProperty"] = str(current_time)
15         h["int8Prtoerty"] = self.newInt
16         instantiate('cppServer/session1', 'PropertyTest', self.name, h)
17         print(f"device {self.name} is instantiated with sting: {current_time}")
18         sleep(10)
19         shutdown(self.name)
20         print(f"device {self.name} shutdown")
21         sleep(2)
22
```