



MTCA.4 Products and Solutions for Accelerators at CAEN ELS

Enrico Braidotti

Sales & Field Application Manager







- Company Profile
- Product Lines and Solutions
- FMC FPGA Mezzanine Cards
 - MTCA.4 Products
 - · Q&As





Company Profile

CAEN ELS d.o.o.

Spin-off company of CAEN Spa

Founded in 2009 in Sežana – Slovenia



Application fields

Oriented and dedicated to particle accelerator facilities e.g. synchrotron light sources, LINACs and Free Electron Lasers

"Know-how" and "hands-on" large installations and maintenance

Industrial capability


Customization and dedicated support





Product Lines

www.caenels.com





Product Lines

www.caenels.com

Digital Magnet Power Supplies

Bipolar + Monopolar

from ±5A (small correctors) to 135A

Ethernet Interface





DC Current Transducers
Closed-loop Technology
DC + AC monitoring up to kA

Complete Digital T&M and Calibration Systems

Multi-channel Low Current Measurements
Dedicated Systems (Bipolar HV for Optics)
Beamline Local Feedback Integrated System - BEST





MicroTCA for Physics
FMC cards
Low-current Measurements and High-Voltage



FMC-Pico-1M4-16

• FMC-Pico-1M4-20

Quad-Channel 16/20-bit 1MSPS Floating Ammeter Card

- Standard FMC Vita 57.1
- Bipolar current-input stage
- Two measuring ranges (±1 mA and
 - configurable upon request
- 16-bit an 20-bit versions
- Up to 1 MSPS
- Floating up to ±300 V

RN 2.	
7 ppm/FS	
-103 dB 10 ppm/FS	Extremely low unbalance between channels (by anal)

 Equivalent Input Noise

 RNGo: ± 1 mA
 RN

 1 ppm/FS
 2.

 -120 dB
 7 ppm/FS

 2 ppm/FS
 7 ppm/FS

 -114 dB
 -103 dB

 F_S = 200 ksps
 5 ppm/FS
 10 ppm/FS

 -107 dB
 -100 dB

 F_S = 1 Msps
 8 ppm/FS
 15 ppm/FS

-102 dB

- Extremely low unbalance between channels (by analog design)
- I2C EEPROM calibration

-96 dB



Vacuum chamber

8-Channel MTCA.4 Floating Ammeter

Based on the DAMC-FMC25 carrier designed by DESY

and produced and supported by CAEN ELS

- 2 picoammeters FMC-Pico-1M4 supported
- Each FMC i.e. 4-channel is floating

Copper


Bervllia

TZM blade

DAMC-FMC25

Figure 1: Gap BPM detector structure

 Avoid ground loops if two different detectors are connected to the same DAMC-FMC25 - e.g. quadrature detectors



Dual- and Quad-channel SFP/SFP+ FMC Adapter

- Designed by DESY and produced and supported by CAEN ELS
- Dual-channel and Quad-channel versions
 - FMC-4SFP+2
 - FMC-4SFP+4 (w/out FMC bezel)
- Wide I/O operating range: V_{ADJ} can vary from 1.5V to 3.3V
- True level conversion of all SFP+ module pincingleding Inc.
- I²C-controlled Oscillator (10-280 MHz)
- Compatible with the DAMC-FMC25 carrier b









AMC - MTCA.4 Boards



Idea: <u>bring the widespread and well-known CAEN</u> VME and NIM HV-modules to the MTCA platform



Thousands of channels sold since 2010



Cooperation with DESY in the Helmholtz Validierungsfond project «MTCA.4 for Industry» (HVF-0016)

Reproduction, transfer, distribution of part or all of the contents in this document in any form without prior written permission of CAEN ELS d.o.o. is prohibited





HV Positive And Negative Double-width AMC

Voltage / Current rating	VME counterpart	Typical application example
6 kV / 1 mA	V6 ₅₃ 4	Micro-channel Plates, Drift Chambers
4 kV / 3 mA	V6 ₅₃₃	Photomultipliers, Drift Chambers, Silicon & Germanium Detectors
500 V / 3 mA	V6519	Semiconductor devices, Diamond Detectors








HV Positive And Negative Double-width AMC

- Double-Width AMC Board Full Size
- MTCA.4 carrier
- Four High-Voltage channels
- Output ratings:
 - 500 V @ 1.5 W
 - 4 kV @ 7 W
 - 6 kV @ 6 W
- Polarity selectable
- Provides infrastructure for management of optional Rear Transition Module (RTM) boards – class D1.1
- DDR₃ On-board Memory (up to 4 Gbit)
- Separate Interlock for each channel and global one
- Stand-by voltage, Ramping, Current Monitoring and Current Limit



Cooperation with DESY in the Helmholtz Validierungsfond project «MTCA.4 for Industry» (HVF-0016)





<u>HV Positive And Negative Double-width AMC</u>

- Floating ground per pair of channels
 - ±20V standard for safety, up to ±500V
- Communication via PCI-e 1x standard
- Gigabit Ethernet Connection on backplane
- User selectable behavior when output current threshold is exceeded:
 - Switch-off
 - Current source mode
- Output voltage ripple :
 - < 12 mV @ MAX P_{OUT} (up to 4 kV)
 - < 4 ppm/FS @ MAX P_{OUT} (up to 6kV)





AMC Dual High-Pin Count FMC Carrier Board

- Double width AMC board MTCA.4 carrier
- Two HPC FMC slots
- Data processing on Virtex-5 FPGA
- Board management on Spartan-6 FPGA
- RTM D1.1 connectivity
- DDR2 memories on both FPGAs
- External clock input on front panel SMA conne
- 4.25 Gbps ("-1") and 6.5 Gbps ("-2") transceive board options



Turnkey solution with dual 4-channel (8-channel) floating picoammeter AVAILABLE!

License Agreement LV75 between DESY and CAEN ELS

Reproduction, transfer, distribution of part or all of the contents in this document in any form without prior written permission of CAEN ELS d.o.o. is prohibited



Thank You for Your Attention!

(Vielen Dank für Ihre Aufmerksamkeit ©)

CAEN ELS d.o.o.

Kraška ulica, 2 6210 Sežana – Slovenia

Tel. +386 (o)5 7313 585 Fax +386 (o)5 7313 587

Mail: info@caenels.com
Web: www.caenels.com

