LASER COMPONENTS

Low light level detection with **APDs**





Outline

- Company background
- APD and SPAD technology
- Applications
- Outlook



- Company background
- APD and SPAD technology
- Applications
- Outlook



Laser Components





Germa



Laser Components GmbH Wernervon-Siemens-Str. 15 82140 Olching Germany info@lasercomponents.com Tel: +49 8142 2864-0

Headquarters and production facility for Optical Coatings

Optical Coatings Optical Substrates Fiber Optics Photon Counter Laser Modules Detector Modules Electronics



Laser Components (UK), Ud. Goldlay House 114 Parkway Chelmsford Essex CM2 7PR United Kingdom info@lasercomponents.co.uk Tel: +44 1245 491 499 Sales office

Laser Components S.A.S.

45 Bis Route des Gardes

info@lasercomponents.fr

Tel: +33 1 39 59 52 25

92190 Meudon

Sales office

France





Laser Components USA, Inc. 9 River Road Hudson, NH 03051 USA info@laser.components.com Tel: +1 603 821 7040 Sales office





Laser Components DG, Inc. 7755 South Research Drive Tempe, AZ 85284 USA Icd@laser.components.com Tel: +1 480 239 9660

Production facility for Avalanche Photodiodes IR Detectors

USA





Canada

Laser Components Canada, Inc. 195 Joseph Carrier J7V 5V5 Vaudreuil-Dorion, Quebec Canada Icc@laser.components.com Tel: +1 450 455 8270 Production facility for

Production facility for Pulsed Laser Diodes



Laser Components



German



Laser Components GmbH Wernervon-Siemens-Str. 15 82140 Olching Germany info@lasercomponents.com Tel: +49 8142 28640 Headquarters and

Headquarters and production facility for Optical Coatings Optical Substrates Fiber Optics Photon Counter Laser Modules Detector Modules Electronics

Single Photon Avalanche Diodes (SPAD)

Laser Components S.A.S.

45 Bis Route des Gardes

info@lasercomponents.fr

Tel: +33 1 39 59 52 25

92190 Meudon

France

Sales office

Laser Components (UK), Ltd.

Goldlav House 114 Parkway

Chelmsford Essex CM2 7PR

info@lasercomponents.co.uk

Tel: +44 1245 491 499

United Kinadom

Sales office



Laser Components USA, Inc. 9 River Road Hudson, NH 03051 USA info@laser.components.com Tel: +1 603 821 7040 Sales office

Avalanche Photodiodes (APD)

Laser Components DG, Inc. 7755 South Research Drive Tempe, AZ 85284 USA Icd@lasercomponents.com Tel: +1 480 239 9660

Production facility for Avalanche Photodiodes IR Detectors

LASER

COMPONENTS



Laser Components Canada, Inc. 195 Joseph Carrier J7V 5V5 Vaudreuil-Dorion, Quebec Canada Icc@laser.components.com Tel: +1 450 455 8270

Production facility for Pulsed Laser Diodes

Laser Components GmbH









- Vision: Development, production and distribution of custom laserbased and optoelectronic components
- Established in 1982
- Located in Olching, Germany
- ISO 9001:2000 certified
- Production of PLD and APD electronics, Photon Counting Modules, Laser Optics, Laser Modules

LC Detector Group, Inc.









- Vision: Produce high performance avalanche photodiodes and subsystems meeting and exceeding market expectations
- Established in 2004
- Located in Tempe, AZ
- ISO certified
- Production of both Si and InGaAs avalanche photodiodes, hybrids



- Company background
- APD and SPAD technology
- Applications
- Outlook



Technologies

- Photomultiplier
- PMT-APD-Hybrid
- Si-PM (APD and SPAD Arrays)
- (Single Photon) Avalanche Diode (APD, SPAD)
- EMCCD, sCMOS, CCD
- Superconducting Nanowires (SNSPD)



APD / SPAD

- APD: Linear mode, Gain: $10^2 - 10^3$
- SPAD: Geiger mode "Gain": $10^6 - 10^8$



Avalanche Photodiodes





Avalanche Photodiodes









- SAE series
 - red-enhanced (peak at 650nm), NIR-enhanced (peak at 880nm)
 - $-~230 \mu m$ and 500 μm , dark current (M=100): 0.5 5 nA
- SAR series
 - with/without TEC, peak at 905nm
 - 500μm, dark current (M=100): 0.5 1.5 nA
- SAP series
 - linear mode and Geiger mode, with/without 1stg/2stg TEC
 - 500μm, dark current: 70 1000 (M=250) pA
- IAG series
 - Peak sensitivity at 1550nm; 80, 250 and 300μm

Avalanche Photodiodes









- With filters
 - SARF series: peak at 905nm, 500μm, 870 940nm range
- Fiber pigtail
- Large area
 - $\,$ SAR series, 1500 and 3000 μm
- UV enhanced
 - SUR series: 260 1000nm, 500 μm
- Different packages available:
 - TO-46 (2 pin, 3 pin)
 - TO-37 (TEC)
 - TO-8 (TEC)
 - SMD





APD with optimized preamplifier, APD-modules

- Si and InGaAs versions available
- H1 series
 - Bandwidths from DC to 25 MHz, TO-8 package
- H2/H3/H4/H5 series
 - Bandwidths from 10 kHz to 700 MHz, TO-46 package
- A-CUBE module

COUNT[®]





COUNT[®]









- VLoK Geiger mode silicon APD
- Built-in TEC \rightarrow -10°C
- Active quenching electronics
- Gating function
- 12V DC voltage supply
- Optional FC/PC connector with AR-coated Grin lens

COUNT[®]









- DE > 70% at 670nm
- DCR < 10cps</p>

- Afterpulsing < 0.5%
- Dead time: 42ns
- Gating function

- DE > 70% at 532nm
- DE > 55% at 405nm
- DCR < 10cps</p>
- Afterpulsing < 0.5%
- Dead time: 42ns
- Gating function





Detection Efficiency



- Company background
- APD and SPAD technology
- Applications
- Outlook



Applications





Applications

Distance Measurement

- Time of Flight
- Phase Modulation
- Absolute Interferometry
- Triangulation





Applications



Industrial Applications

- Surveying equipment
- Security barrier
- 3D Imaging and Profile Scanner
- Ceilometer
- Laser Distance Meter for construction









Applications







Military

- Range Finding up to 10km
- "Friend or Foe" identification
- Telemetry / Weapon Simulation
- Proximity Fuse



Applications

Automotive

- ACC (Adaptive Cruise Control)
- Automated Toll Collection
- Speed Guns
- Traffic Control









Applications

Commercial and Medical

- Rangefinder for Hunting, Golf...
- Speed guns for sports
- Laser induced accelerated healing
- Diagnostic ophthalmology









Applications

Single Photon Counters are used for

- Particle sizing
- Confocal microscopy
- Time-resolved fluorescence detection
- Astronomy
- Quantum cryptography
- Spectroscopy

Applications

Particle Sizing

- Dynamic light scattering / Photon Correlation Spectroscopy
- Doppler shift measurement on moving particles
- Particle diameter from <1 nm to > 1 μm





Figure 1: Schematic diagram of a conventional, 90° dynamic light scattering instrument.

Applications

Confocal Microscopy

- Laser-induced fluorescence
- Point sensor principle
- Reduced depth-of-field = higher resolution







Applications

Astronomy

- Long-range LIDAR
- Adaptive telescope optics







Applications

Quantum Cryptography

- Quantum key distribution use of quantum communication to securely generate a key for two parties (Alice & Bob) to securely communicate
- Immune to eavesdropping any third party attempt (Eve) will disrupt the quantum states of the photons









Conclusion

Outlook

- 10mm LARS series
- APD arrays
- Timing SPAD with 200-400ps jitter
- Your product!



Thank you for your attention!