



Cornell University  
Laboratory for Elementary-Particle Physics



# Status of Fabrication and Test of the Cornell ERL Injector Cryomodule

*Eric Chojnacki*

Cornell University

Laboratory for Elementary-Particle Physics

**TESLA Technology Collaboration (TTC) Meeting at Fermilab, April 23-26, 2007**

---



- A nice report on ERL Injector considerations was presented by Sergey Belomestnykh at the ERL 2005 Workshop at JLAB:  
<http://www.lns.cornell.edu/public/ERL/2005/ERL05-10/ERL05-10.pdf>
- ERL Injector Beam Requirements
- ERL Injector SRF Answers
- Cornell ERL Injector Innovations
- Cornell ERL Injector Components
- Cornell ERL Injector Schedule
- Cornell ERL Injector 1-cell Horizontal Test Cryomodule




- Energy gain 5-15 MeV
- High CW current, 100 mA @ 5MV, 33 mA @ 15MV
- Low emittance, 0.1-1 mm-mrad
- Short bunch, 0.6 mm



# ERL Injector SRF Answers

- 2 coax couplers per cavity for beam-impedance symmetry, one 120 kW CW klystron per coupler pair
- 2 cells per cavity  $\leq 15$  MV/m deliver all klystron power to beam
- 5 cavities for 5-15 MeV energy gain
- Beamline HOM Loads for aggressive damping due to high current and short bunches





# ERL Injector Philosophy

- Use the same cryomodule concept in Injector and main linac.
- Rely on well established and tested performance of the TESLA technology to reduce risk and minimize development time.
- TESLA module has already had several iterations to reduce cost, continue simplification and cost reduction with the Injector to apply to the ERL linac.



- Precision fixed surfaces between the beamline components and the HGRP, easy “self” alignment
- HGRP alignment with VV under vacuum
- In-situ bake for cold and warm couplers, no further atmosphere exposure, *no pre-conditioning*
- Tuner stepper easily replaceable while string is in cryomodule
- WPM with jellybean electronics
- 80K and 5K He HEX in Cryo can

## Other changes compared to TESLA module

- CW operation with high beam currents.
- Reduced module length for ERL Injector.
- 2-cell cavities instead of 9-cell cavities.
- Larger tube diameter.
- Stainless steel cavity flanges.
- HOM absorbers between cavities.
- Pipes for HOM and Coupler cooling.
- No 5K shield, only a cooling manifold.
- Increase diameter of 2-phase 2K He pipe to 10 cm for CW operation.
- Improve magnetic shielding for very high  $Q_o$ , 3 layers.
- Two 62 mm ID input couplers instead of one 40 mm. Increased cooling for high average power.
- New end-cap and feed-cap concept with reduced length.




- Cavity
- Input coupler
- HOM dampers
- Tuner
- Cryogenics






# ERL Injector Cavity

Frequency	1300 MHz
Cells per cavity	2
R/Q	$222 \Omega$
Voltage	1-3 MV
Gradient	5-15 MV/m
$Q_o$ @ 2K	$>10^{10}$
$Q_{\text{ext}}$	$4.6 \cdot 10^4 - 4.1 \cdot 10^5$
Active length	0.218 m
Total length	0.536 m



- Ti He vessel
- Brazed conflat flanges
- Mild multipactor at large beam tube transition, very easily processed in vertical tests








# ERL Injector Cavity

- 5 cavities tested, all meet specs,  $E > 15$  MV/m (most  $E > 20$  MV/m) ,  $Q > 10^{10}$  @ 2K
- Only BCP, no 800C treatment
- Two tested for H disease, no H disease





# ERL Injector Input Couplers


Tuesday 24 April 2007

*13:45->15:30 WG 4: Input & HOM coupler*

13:55 High power tests of the prototype input couplers for the  
Cornell ERL injector (20') **S. Belomestnykh (Cornell)**



- Proto-types tested to 50 kW CW, 80 KW pulsed, designed for 75 kW CW










# ERL Injector HOM Dampers


Total # loads	3 @ 78mm + 3 @ 106mm
Power per load	26 W (200 W max)
HOM frequency range	1.4 – <b>100 GHz</b>
Operating temperature	80 K
Coolant	He Gas
RF absorbing tiles	TT2, Co2Z, Ceralloy





# ERL Injector HOM Dampers

2 proto-types fab'ed by LEPP  
6 production loads fab'ed by ACCEL








# ERL Injector Tuner

- Modification of a DESY proto-type INFN blade tuner, collaboration with UPenn
- Added piezos
- Stepper motor easily replaceable while cavity string is in cryomodule
- $\mu$ phonics feedback bandwidth using tuner:  $\sim 0.1$  Hz stepper +  $\sim 1000$  Hz piezo
- Cavity frequency bandwidth: 500 kHz stepper + 5 kHz piezo







# ERL Injector Tuner






# ERL Injector Cryogenics




2K Cavity	25 W
5K Coupler + HOM Load	68 W
80 K Coupler	696 W







# ERL Injector Cryovessel



- Injector length 5m
- Careful cost tracking
- Close interaction with vendors




# ERL Injector Schedule

- 6 Cavities fab'ed and vertical tested at LEPP, 5/07
- 6 Tuners fab'ed by Incodema, delivered 4/07
- 6 HOM loads fab'ed by ACCEL, 7/07
- 10 Couplers fab'ed by CPI, 6/07-8/07
- Cryovessel drawings ACCEL, 4/07
- Cryovessel bids 5/07, delivery 9/07
- Cryomodule assembly 8/07 – 1/08



# ERL Injector Horizontal Test

- Perform a horizontal test of a 1-cavity cryomodule to de-bug the Injector design, the Horizontal Test Cryomodule (HTC)
- Use LEPP proto-type HOM Loads
- HTC cryovessel fab'ed by Meyer Tool & Mfg, delivered 2/07 – 4/07
- HTC assembly in progress
- HCT test 6/07





- HTC animation





# ERL Injector Horizontal Test

The HTC Vacuum Vessel  
will also be used as an ERL  
Linac 5-cell cavity test  
cryomodule





## *Cornell ERL SRF Team*

H. Padamsee  
M. Liepe  
S. Belomestnykh  
E. Chojnacki  
J. Sears  
R. Geng  
V. Medjidzade  
D. Meidlinger  
V. Veshcherevich  
V. Shemelin

P. Quigley  
D. Heath  
P. Barnes  
B. Clasby  
J. Kaufman  
A. Windsor  
R. Roy  
R. Ehrlich  
E. Smith