

MTCA.4 at Wendelstein 7-X

T. Bluhm¹, H. Laqua¹, A. Winter¹, M. Zilker²

¹Max-Planck-Institut für Plasmaphysik, Wendelsteinstr. 1, Greifswald, Germany

²Max-Planck-Institut für Plasmaphysik, Boltzmannstr. 1, Garching, Germany

HELMHOLTZ

RESEARCH FOR GRAND CHALLENGES




EUROfusion

This work has been carried out within the framework of the EUROfusion Consortium and has received funding from the Euratom research and training programme 2014-2018 under grant agreement No 633053. The views and opinions expressed herein do not necessarily reflect those of the European Commission.

- 1 Wendelstein 7-X Introduction
- 2 MTCA.4/ATCA by Example
- 3 Outlook

Wendelstein 7-X (W7-X)

- is located in Greifswald (Germany) near the Baltic Coast
- employs about 400 scientists, engineers, administrative staff
- investigates the basics for energy production from nuclear fusion
- aims at quasi-continuous operation → goal: 30 min




Find out more at

<http://www.ipp.mpg.de/w7x>

- W7-X operates about 50 diagnostic systems to observe and analyze the experiment
- a wide range of different acquisition hardware used
- Diagnostic examples using MTCA.4 and ATCA hardware:
 - Thomson Scattering
 - Coil Isolation Supervision
 - Dispersion Interferometry
 - Magnetic Equilibrium

Diagnostic Goal

- acquisition of light from monochromatic IR lasers scattered on the free electrons of the plasma
→ information about electron temperature and density




Acquisition Parameters

- Number of channels: 220
- Sample Frequency: 1 GHz
- Acquisition Method: pulsed (triggered by laser pulses)
- 2000 samples acquired on each pulse


Hardware

- 5x 12-slot Schroff MTCA.4 shelf
- in each shelf:
 - 1x Concurrent AM-90X CPU
 - 11x SPDevices ADQ14DC-4C



Issues

- 10 MHz Reference clock distribution over backplane for synchronization of all ADC cards to central W7-X time system
→ solved with MCH Firmware upgrade provided by N.A.T.
- Trigger distribution over backplane to avoid individual cables to each ADC card
→ solved with ADQ14 Firmware Upgrade provided by SP Devices
- some temperature and voltage sensors unavailable via MCH
→ solved by MCH firmware upgrade (FPGA & MMC)



Reference Clock Trigger

Diagnostic Goal

- detection of possible RF emission in case of HV discharges on the superconducting coil system using five RF antennas
→ prevention of severe damage to the superconducting coils

Acquisition Parameters

- Number of channels: 5
- Sample Frequency: 1 GHz
- Acquisition Method: pulsed (triggered by threshold)
- variable number samples on each pulse ($1\mu\text{s}$ to 10ms)


Hardware

- 1x 6-slot powerBridge RackPak MTCA.4 shelf
- 1x Concurrent AM-90X CPU
- 2x Signal Processing Devices ADQ14DC-4C



Issues


- triggering of acquisition by threshold violation on *any* of the five input channels distributed over *two* ADC boards
→ solved with custom firmware developed by SP Devices



Source: Daisy-chained level trigger, SP Devices, Sweden (2017)


Diagnostic Goal

- measurement of line integrated electron density from plasma induced changes in the optical path length



Acquisition Parameters

- Number of channels: 2
- Sample Frequency: 50 MHz
- Acquisition Method: continuous (limited by experiment program - currently max. 100s)




Hardware

- 1x 6-slot powerBridge RackPak MTCA.4 shelf
- 1x Concurrent AM-G6x CPU
- 1x Struck SIS8300

Issues


- custom FPGA firmware for density feedback control and interlock generation
 - developed in-house¹
 - PCIe interface to CPU realized with Xillybus FPGA IP core
- AM-G6x 10Gbit network interface
 - about 2 Gbit/s streaming data rate required for continuous operation
 - initially SFP module detection failed
 - solved with BIOS updated of CPU module



¹Real-time dispersion interferometry for density feedback in fusion devices, K.J. Brunner et al, 2018, <https://doi.org/10.1088/1748-0221/13/09/P09002>

Diagnostic Goal

- measurement of changes of the magnetic flux of the plasma using a system of magnetic coils
→ information about the plasma energy



Acquisition Parameters

- Number of channels: 294
- Sample Frequency: 2 MHz
- Acquisition Method: continuous (limited by experiment program - currently max. 100s)




Hardware


- 10x 2-slot Artesyn Centellis 2000 ATCA shelf
- in each shelf:
 - 1x IST ATCA-MIMO-ISOL board
 - 1x RTM board for external clock & trigger
 - 1x eicSys EATCA-PCIe-EX ATCA to PCIe expansion board

Issues

- two firmware versions:
 - 1 Standard version (32 channels, 16 Bit)
 - 2 Interlock version (6 channels, 18 Bit + Interlock Data)
- custom development of RTM board at IPP (SimpleRTM)
→ simple I/O for gate and clock triggers



Source: ATCA-MIMO-ISOL User Manual V1.0, IST, Portugal



SimpleRTM, IPP

Extension of existing systems

- Thomson Scattering: 480 channels
- Interferometry: 10 channels

Camera Support

- development of Camera Link and GigE Vision interface boards on MTCA FMC carrier
- FPGA based real-time image processing for supervision tasks

Additional Custom Boards

- further board developments based on FMC carrier (e.g. W7-X Bolometer)

**Thank you
for your attention!**