Overview of DMCS Projects and MicroTCA.4 Developments

DSc Dariusz Makowski, Associate Professor Lodz University of Technology



Plasma Diagnostics

Diagnostic Systems provide data for:

- Plasma Diagnostics, physics study (non-real-time)
 - Physical studies, observation, measurements
 - Archiving measurements, raw data could be challenging (transferring and archiving ~TBs of data)
 - Stored data: raw data, pre-processed, calibrated, measurements, metadata (labels, tags)
 - Important for ML and AI
- Machine and Plasma Control (real-time, soft real-time)
 - Diagnostic systems supply information for Plasma Control System
 - Primary and supplementary systems
 - Latency from 10 100 ms
- Machine Protection (hard real-time)
 - Trigger interlocks to protect machine against damage
 - Latency from 100 1000 ms



ITER Plasma Diagnostics

- Imaging Diagnostics
 - Divertor IR Thermography (IRTh)
 - Camera Link and 10GigE Vision
 - Boundary Imaging System (BIS)
 - CoaXPress
 - Upper Wide Angle Viewing System (UWAVS)
 - 10GigE Vision
 - H-Alpha and Visible Spectroscopy Diagnostic
 - Camera Link High Speed
- Spectroscopic Diagnostics
 - Hard X-Ray Monitor (HXRM)
 - Radial Gamma Ray Spectrometer (RGRS)
 - High Resolution Neutron Spectrometer (HRNS)
- And a few more systems, but no time today...



Fusion Projects - Plasma Diagnostics

Imaging diagnostics:


ITER Tokamak

→ W7-X:

17 VIS and 13 IR cameras (OP2.1-OP2.5)


ITER:

more than 200 VIS and IR cameras





IR Diagnostics





Wendelstein 7-X Stellarator








Imaging Diagnostics – Image Acquisition and Processing (1)

- A single camera provides one or more streams of images
- Frame grabber configures camera, start and stop DAQ
- All operations must work in <u>real-time</u> (hard real-time system)
- Developed reliable, scalable and standardized solution (hardware/software) suitable for Al and ML real-time applications



Image Acquisition and Processing with MicroTCA.4 (2)



Universal Frame Grabber Module for MicroTCA.4

Frame grabber is composed of:

- ◆ FMC carrier (FPGA, DDR, PCIe, trigger, etc.)
- FMC modules supporting various camera interfaces (8 standards)

In addition, we need (**software**):

- FPGA firmware
 - IP core for selected camera interface
 - Xilinx (IP Cores, Vivado)
- Linux driver
 - Dedicated camera library
- Image processing framework
- Additional tools
 - Visualisation application



Carrier module + Mezzanine module




FMC Carrier Modules

Frame grabber is composed of:

- FMC carrier
 - Artix 7 FPGA (<6.5 Gb/s)</p>
 - Kintex US+ (>6.5 Gbps, 32 Gb/s per lane)
- Mezzanine modules (FMCs) supporting various camera interfaces (8 standards)
 - Galvanically isolated IO module

Software support:

- IP cores for selected camera interfaces
- Common Linux driver
- Dedicated camera library (GenICam)
- Real-time processing software
- Algorithms (FPGA, CPU, GPU)








Universal Frame Grabber Module - Software

- FPGA firmware
- Linux driver
- Frame grabber library
- Camera library
- Tools for camera configuration
- Tools for image visualization
- Real-time image processing



FPGA

firmware

Hardware we have now
Software is actually the main part of work

Working on an universal IA and IP framework









Image Acquisition Software Framework Based on GenlCam





Imaging Diagnostics – Latency Measurements







Frame Grabbers and Supported Interfaces

Low Performance



- Camera Link (basic, medium, full, single, dual)
- 1 GigE Vision



- CoaXPress 1.1 (CXP-1...CXP-6) CoaXPress
- Fire Wire (S800, S1600, S3200)
- Serial Digital Interface (3G-SDI, 6G-SDI)



- HDMI (both input and output)
- Digital low-latency IO module (various variants)

High Performance

Camera Link High Speed



10/25 GigE Vision



CoaXPress 2.0 (CXP-10, CXP-12)



Digital low-latency IO module (various variants)
















55.G6 - Divertor IR Thermography

- Surface temperatures and power loads on divertor and baffles
- ◆ Temperature: 200°C 3600°C
- Time resolution: from 35 µs to 2 ms
- Wavelength range: 1.5 μm 4.5 μm
- → FLIR camera with 10 GigE interface
- Alignment camera with Camera Link
- → Resolution: 640 × 512 px










55.GE - Boundary Imaging System

Detects ELMs (20 µs) and LH D-Alpha step

- Camera
 - Mind Vision MV-PXL164BM
 - Resolution: 16384 x 4 @ 56 kHz
 - Tested with CXP6-4
- Frame Grabber
 - High-performance carrier
 - Supports CoaXPress 2.0
 - CXP12-4 up to 4 lanes
 (4x 12.5 Gbps, total 50 Gbps)
 - PCIe 8-lanes, gen. 3
 - External trigger output
 - GenlCam interface





55.GA - Upper Wide Angle Viewing System

Frame Grabber

- High-performance carrier, 10 GigE
- PCIe 8-lanes, gen. 3
- External trigger output
- GenlCam interface
- Frame grabber latency:
 130.01 us, std: dev. 39.31 us
 for 4096x3068 resol.

Baumer VQXT-120M.HS



Emergent HR-12000M



Camera


VIS:

Emergent: 4096x3068 Baumer: 4096x3068

IR: not yet selected



Upper Wide Angle Viewing System (2)



55.E2 - H-Alpha and Visible Spectroscopy Diagnostic

Camera


- PCO Edge 5.5
- Resolution: 2560x2160 @ 100 fps
- Exposed to neutrons and gamma radiation

Frame Grabber

- Supports Camera Link HS
- High performance frame grabber
- External trigger output
- GenlCam interface













Framework for Images Visualisation on Large Scale Display






Hard X-Ray Monitor

- Run-away Electrons measurements
 - Measures X-ray radiation (5 20 MeV)
 - PMT with scintillator
 - Connected using ~11 m long fibre bundle
 - Uses 1 GS/s ADQ14 digitiser






Light attenuation affecting the PMT signal (Co-60 radiation source)




Hard X-Ray Monitor

- Run-away Electrons measurements
 - PMT pulses have a different shape
 - Current algorithms for PMT pulses discrimination do not work
 - ITER data not available results need to simulated





Simulation results for 2.26% Optical Transmission Efficiency





Arbitrary Waveform Generator dedicated for MTCA.4

- Provides emulated signal for HXRM system for algorithms development, testing and performance evaluation
- Two variants: 500 MS/s and 1 GS/s, 2 or 4 channels, 16-bit
- Output voltage: ±5 V (Z=50 R)
- Uses low- or high-performance carrier (16 GB of DDR)
- Fully synchronised with digitiser and ITER timing (PTP1588)
- Provides samples from DDR memory or CPU



Summary

- Processing of images from VIS or IR cameras for fusion requires a flexible and scalable hardware platform
- Developed and evaluated low latency solutions for Mega Pixel cameras
- FPGA and GPU could be used for executing AI-based algorithms
- Developed frame grabbers supporting various camera interfaces
- Developed universal software framework based on GenICam
- Developed a dedicated solution based on NVIDIA GPUDirect RDMA solution that significantly reduces the total image processing latency and releases the CPU
- Working on real-time AI algorithms and design methodology

Looking for imaging solution – contact with us





Thank you for your attention